

TREATMENT HARD STONE MARBLE - SLATE OUTSIDE - INSIDE

IMPREGNATING – WATERPROOF ENHANCES THE COLOUR

0527

This treatment protects hard stone, marble and slate oil stains, grease, water. It leaves no visible film.

<u>APPLICATION</u>

This should not applied at less than 15 degrees, on warm soil or in the sun. It should be applied in 2 or 3 layers on a new or old floor which is clean and dry, with no trace of other treatment which would result in poor penetration and poor drying of the product.

On a new floor: when the soil is dry, apply 0527 with a brush or a mop in regular crosslayer. Ensure a good distribution and that there is no surplus. Allow 4-8 hours drying time.

On an old floor: it should be cleared of any prior treatment, use our powerful cleaner 0901. When the soil is dry and ready for 0527 as described above.

FINISH

For the interior near drying of 72 h or more, we can apply a finish that will give a satin look with our palm wax emulsion or a brilliant 0722 with our incomparable skate wax 0007.

SECURITY

- Please read the security instructions carefully
- work in a well aired room
- wear rubber gloves
- keep out of reach of children

This information is given here in good faith but does not involve our responsibility.