

## TECHNICAL DATASHEET

# TREATMENT FOR CEMENT TILES & STONE WARE

# IMPREGNATING - WATERPROOF 0531

### **OUTSIDE - INSIDE - IMPERCEPTIBLE**

This treatment protect your tiles from oil stains, grease, water. It leaves no visible film.

#### **APPLICATION**

This should not applied at less than 15 degrees, on warm soil or in the sun. It should be applied in 2 or 3 layers on a new or old floor which is clean and dry, with no trace of other treatment which would result in poor penetration and poor drying of the product.

On a new floor: when the soil is dry, apply 0531 with a brush or a mop in regular cross-layer. Ensure a good distribution and that there is no surplus. Allow 4-8 hours drying time.

On an old floor: it should be cleared of any prior treatment, use our powerful cleaner 0901. When the soil is dry and ready for 0531 as described above.

#### *FINISH*:

For the interior near drying of 72 h or more, we can apply a finish that will give a satin look with our palm wax emulsion or a brilliant 0722 with our incomparable skate wax 0007.

### Security:

Please read the security instructions carefully

🦊 work in a well aired room

wear rubber gloves

keep out of reach of children

This information is given here in good faith but does not involve our responsibility.